



# System Options & Accessories



## **ENCLOSURE**

#### KE-8

Keri's KE-8 enclosure facilitates the mounting of four PXL- 500's with SB-593 option boards or four NXT controllers in a convenient, secure metal enclosure (wall or IT rack-mountable).

## UNIVERSAL DESKTOP ENROLLMENT READER

#### **RDR-ENR1**

Keri's desktop card-reader combines proximity and contactless technologies into a universal desktop reader for presentation enrollment at a computer location.



- Integrated with Doors.NET software
- Reads a variety of popular 3rd party 125 kHz proximity cards and 13.56 MHz smart cards
- Plugs directly into a PC's USB port

## **POWER SUPPLIES**

Keri offers several power supplies perfectly matched to the NXT, PXL, and Entraguard hardware products.

### KPS-11

+12VDC@10A Especially useful for IT rooms and other applications with centrally located controllers.



KPS-4-1 without enclosure KPS-5-1 with enclosure +12VDC@2.5A Powers up to 4 doors of either PXL or NXT hardware.



## **AUTO-USB NETWORKING**

#### **USB-A**

Provides the advantages of a TCP/IP-based system in an easy-to-configure, plug & play format. Using standard Ethernet components and wiring, AutoUSB requires no Ethernet knowledge or approval from most customers' IT Departments.



- Connects NXT Hardware via USB Port on PC
- Plug-and-Play connectivity and functionality
- All controller addressing done automatically
- Greatly simplifies setup and configuration for systems up to 256 Readers

## **SERIAL COMMUNICATIONS MODULE**

#### **SW-SCM**

Connects PXL-500 Master Controller to PC's USB port, and comes with a 15'ft cable (4.57 meters)



#### LAN-PORT CONNECTOR

### LAN-520-AESP

For connecting PXL-500 Master Controller to host computer via TCP/IP (shown mounted with NC-485X)



### **ETHERNET CONVERTER**

#### NC-485 to RS-485

Pairs with and mounts on LAN-520-AESP to use Ethernet connectivity to bridge PXL-500 RS-485 network

